



ANTELOPE

by beurer

USER MANUAL

CONTACT CUSTOMER CARE

In case you have any further questions or queries regarding your ANTELOPE.TECHWEAR, please contact our Customer Care Team:



info@antelope.de



www.antelope.de



+49 69 25786744



ANTELOPE - part of the Beurer group - BEURER GmbH

ANTELOPE.TECHWEAR

This user manual forms part of the delivery scope of the ANTELOPE.TECHWEAR.

The instruction manual is aimed at the end user. You must be in a position to read and understand the information contained in this instruction manual and the accompanying documents.

This instruction manual must be kept in a well-known, easily accessible location at all times, and ANTELOPE - part of the Beurer group - BEURER GmbH must be consulted if any issues or slightest doubts arise.

ANTELOPE - part of the Beurer group - BEURER GmbH accept no liability for damage to persons, animals, property or to the product itself which arise from improper use, failure to observe or inadequate observation of the safety criteria contained in this user manual, or any alterations to the ANTELOPE.TECHWEAR or the use of unsuitable replacement parts (non-original parts).

The ANTELOPE.TECHWEAR user manual carefully indicates situations and risks by means of symbols and safety instructions.

IMPORTANT:

Please always refer to this user manual in order to avoid malfunction and injury.

There are generally four warning levels, identified by the corresponding symbols:

CAUTION

Indicates a hazard with a low level of risk which, if not avoided, could result in minor or moderate injury.

WARNING

Indicates a hazard with a medium level of risk which, if not avoided, could result in serious injury and equipment damage.

DANGER

Indicates a hazard with a high level of risk which, if not avoided, will result in death or serious injury.

NOTE

Indicates information helpful in particular areas or functions.



TABLE OF CONTENTS

1. INTRODUCTION	4	8. INSTRUCTIONS FOR USE	10
2. INTENDED USE	4	8.1 Putting on the ANTELOPE.SUIT	10
3.PURPOSE	4	8.2 Putting on the ANTELOPE.TANK-TOP	10
4. INDICATIONS	5	8.2.1 Connecting the ANTELOPE.TANK-TOP and the ANTELOPE.2C-BOOSTER	11
5. DISCLAIMER	5	8.3 Putting on the ANTELOPE.CALF-GUARDS	11
6. CONTRAINDICATIONS	6	8.3.1 Connecting the ANTELOPE.CALF-GUARDS and the ANTELOPE.2C-BOOSTER	11
PRECAUTIONS:	6	8.4 Switching the ANTELOPE.2C-BOOSTER and ANTELOPE.8C-BOOSTER ON/OFF	11
7. SCOPE OF SUPPLY	7	8.5 Connecting the ANTELOPE.2C-BOOSTER and	12
7.1 ANTELOPE.SHIRT	7	ANTELOPE.8C-BOOSTER to the ANTELOPE.APP via Bluetooth	12
7.2 ANTELOPE.SHORTS	7	8.6 Starting the Stimulation	12
7.3 ANTELOPE.8C-BOOSTER	7	8.7 Regulating Stimulation.....	12
7.4 ANTELOPE.TANK-TOP	8	8.7.1 Ending the Stimulation	13
7.5 ANTELOPE.CALF-GUARDS	8	8.8 Using the ANTELOPE.2C-BOOSTER and ANTELOPE.8C-BOOSTER.....	13
7.6 ANTELOPE.2C-BOOSTER	8	8.8.1 Battery status.....	13
7.7 ANTELOPE.APP	9	8.8.2 Charging the BOOSTER.....	13
7.8 ANTELOPE.SPRAY.....	9		
7.9 BOOSTER Charging Cable	9		



9. TROUBLE SHOOTING	14
10. SAFETY INSTRUCTIONS	16
11. CARE AND MAINTENANCE	17
11.1 BOOSTER CARE	17
11.2 Washing instructions.....	17
12. DISPOSAL	17
13. CLAIMS FOR DEFECTS / WARRANTY	18
14. LABELS	19
15. TECHNICAL SPECIFICATIONS	20
15.1 ANTELOPE.8C-BOOSTER.....	20
15.2 ANTELOPE.2C-BOOSTER.....	20
16. COMPANY INFORMATION	21



1. INTRODUCTION

ANTELOPE.TECHWEAR uses Electrical Muscle Stimulation (EMS) for high intensity training units

A condition of safe use is the responsible handling of ANTELOPE.TECHWEAR. In order to reduce risk this user manual must be carefully read before use of ANTELOPE.TECHWEAR.

SCOPE OF SUPPLY:

- ANTELOPE.SUIT
 - ANTELOPE.SHIRT
 - ANTELOPE.SHORTS
- ANTELOPE.8C-BOOSTER
- ANTELOPE.TANK-TOP
- ANTELOPE.CALF-GUARDS
- ANTELOPE.2C-BOOSTER
- BOOSTER Charging Cable
- ANTELOPE.SPRAY
- ANTELOPE.APP

Available to download on iOS and Andriod.

- IOS: <https://itunes.apple.com/de/app/antelope-de/id1139453110?mt=8>
- ANDROID: <https://play.google.com/store/apps/details?id=club.antelope.app&hl=en>

2. INTENDED USE

The ANTELOPE.TECHWEAR is an Over-The-Counter device intended to stimulate healthy muscles in order to improve or facilitate muscle performance. This product should be used by adults only.

The ANTELOPE.TECHWEAR is not intended for adjunctive therapy in the treatment of medical diseases. None of the ANTELOPE.TECHWEAR stimulation programs are designed for injured or disease afflicted muscles. Its use on such muscles is contraindicated. The stimulation imposed on the muscles by the ANTELOPE.TECHWEAR programs is definitely not suitable for rehabilitation and physiotherapy.

Electrical muscle stimulation may therefore be considered a technique of muscle training and should only be used for this purpose.

3.PURPOSE

The ANTELOPE.TECHWEAR series stimulates the healthy muscles to improve performance of human body or general well being. It is intended to be used by healthy adults only.



4. INDICATIONS

The ANTELOPE.TECHWEAR is intended to stimulate healthy muscles in order to improve or facilitate muscle performance. It is to be used by adults only.

Depending on the parameters of the electrical impulses (pulse frequency, duration of contraction, duration of rest, total session duration), different types of muscle work can be imposed on the stimulated muscles.

Only use the ANTELOPE.TECHWEAR when you are fully regenerated. Follow our workout instructions and also work out without the ANTELOPE.TECHWEAR regularly.

5. DISCLAIMER

Before using ANTELOPE.TECHWEAR please consult a physician. The following points should be taken into account. If one or more of the following apply to you, you must NOT use ANTELOPE.TECHWEAR for safety reasons:

- You have a cardiac pacemaker or other electrical implant(s)
- You are pregnant
- You have a severe neurological, cardiovascular or tumour diseases
- You have a serious disease (i.e. fever, infections, inflammations)
- You have muscle ache/soreness
- You have muscle spasms

CAUTION

Do not use the ANTELOPE.TECHWEAR on injured skin or to stimulate the muscles of an afflicted limb or joint.

A possible side-effect of unfamiliar and intensive training is damage to the muscle tissue. This comes with the partial loss of strength, delayed muscle soreness and a significant increase of muscle protein levels (e.g. creatine kinase levels) found in the blood. Especially after the first intense training sessions with the ANTELOPE.TECHWEAR there is a heightened risk of muscular damage.

Please follow our instructions carefully to avoid some of the problems mentioned before.



6. CONTRAINDICATIONS

1. Powered muscle stimulators should not be used on patients with cardiac demand pacemakers.
 2. The long-term effects of chronic electrical stimulation are unknown.
 3. Stimulation should not be applied over the neck or mouth. Severe spasm of the laryngeal and pharyngeal muscles may occur and the contractions may be strong enough to close the airway or cause difficulty in breathing.
 4. Stimulation should not be applied across the chest in that the introduction of electrical current into the heart may cause cardiac arrhythmias.
 5. Stimulation should not be applied to the head.
 6. Stimulation should not be applied over swollen, infected, or inflamed areas or on skin eruptions.
 7. Stimulation should not be applied over, or in proximity to, cancerous lesions.
 8. If you are pregnant you should avoid training with electronic muscle stimulation.
3. Caution should be used in the presence of the following:
 - a. When there is a tendency to bleed because of injury;
 - b. Following recent surgical procedures when muscle contraction may disrupt the healing process;
 - c. Over the menstruating or pregnant uterus; and
 - d. Over areas of the skin which lack normal sensation.
 4. Electrode placement and stimulation settings should be followed in accordance with this manual.
 5. Powered muscle stimulators should be kept out of the reach of children.
 6. Powered muscle stimulators should be used only with the leads and electrodes recommended for use by the manufacturer.
 7. Powered muscle stimulators should not be used while driving, operating machinery, or during any activity in which involuntary muscle contractions may put the user at undue risk of injury.

ADVERSE REACTIONS

Some users may experience skin irritation or hypersensitivity due to the electronic stimulation or electrodes. The following points may indicate serious damage to the muscle tissue (rhabdomyolysis). If you find yourself displaying one of these symptoms please contact a physician:

- Brown urine
- Myalgia (severe muscular pain)
- Extreme swelling of the muscle



7. SCOPE OF SUPPLY

7.1 ANTELOPE.SHIRT

The fabric of the ANTELOPE.SHIRT consists of 54% polyamide, 36% polypropylene and 10% elastane. The ANTELOPE.SHIRT includes ten silicone electrodes integrated into the compression fabric. A baseplate with magnetic buttons attached to the shirt enables the textile to be connected with the ANTELOPE.8C-BOOSTER.

The ANTELOPE.SHIRT is only intended for training the neck, upper arm, chest, abdomen and back. In combination with the ANTELOPE.SHORTS, the ANTELOPE.SHIRT comprises the ANTELOPE.SUIT.

NOTE

The shirt can be connected individually to the ANTELOPE.8C-BOOSTER. A muscle stimulating training without the ANTELOPE.SHORTS is possible.

7.2 ANTELOPE.SHORTS

The fabric of the ANTELOPE.SHORTS consists of 54% polyamide, 36% polypropylene and 10% elastane. The ANTELOPE.SHORTS includes six silicone electrodes integrated into the compression fabric. A connection cable with magnetic buttons hangs from the ANTELOPE.SHORTS to enable the textile to be connected with the ANTELOPE.8C-BOOSTER.

The ANTELOPE.SHORTS are only intended for training the hamstrings and gluteal muscles. In combination with the ANTELOPE.SHIRT, the ANTELOPE.SHORTS comprise the ANTELOPE.SUIT.

NOTE

The ANTELOPE.SHORTS cannot be used directly without the shirt. If you only want to use the functions of the shorts, please put on the complete ANTELOPE.SUIT and choose the relevant muscle parts in the ANTELOPE. APP.

7.3 ANTELOPE.8C-BOOSTER

The ANTELOPE.8C-BOOSTER is the energy source of the ANTELOPE.SUIT. The 8C-BOOSTER is equipped with a rechargeable lithium-ion battery.

The stimulation intensity is adjustable by pressing the [+/-] button on the BOOSTER.

- By pressing [+] you increase the intensity of all channels by one unit
- By pressing [-] you decrease the intensity of all channels by one unit

The ANTELOPE.2C-BOOSTER should be charged using the Booster Charging Cable and a standard USB-Charger. The ANTELOPE.8C-BOOSTER is intended only to power and regulate the electrical stimulation for the ANTELOPE.SUIT.



7.4 ANTELOPE.TANK-TOP

The fabric of the ANTELOPE.TANK-TOP consists of 54% polyamide, 36% polypropylene and 10% elastane.

The ANTELOPE.TANK-TOP includes four silicone electrodes integrated into the compression fabric. Magnetic buttons attached to the ANTELOPE.SUIT enables the textile to be connected with the ANTELOPE.2C-BOOSTER with external cables.

The ANTELOPE.TANK-TOP is only intended for training the abdomen and back.

7.5 ANTELOPE.CALF-GUARDS

The fabric of the ANTELOPE.CALF-GUARDS consists of 54% polyamide, 36% polypropylene and 10% elastane.

The ANTELOPE.CALF-GUARDS include two silicone electrodes integrated into the compression fabric. Magnetic buttons attached to the ANTELOPE.CALF-GUARDS enables the textile to be connected with the ANTELOPE.2C-BOOSTER with external cables

The ANTELOPE.CALF-GUARDS are only intended for training the calves.

7.6 ANTELOPE.2C-BOOSTER

The ANTELOPE.2C-BOOSTER is the energy source of the ANTELOPE.TANK-TOP and ANTELOPE-CALF-GUARDS. The ANTELOPE.2C-BOOSTER is equipped with a rechargeable lithium-ion battery.

The stimulation intensity is adjustable by pressing the [+/-] button on the BOOSTER.

- By pressing [+] you increase the intensity of all channels by one unit
- By pressing [-] you decrease the intensity of all channels by one unit

The ANTELOPE.2C-BOOSTER should be charged using the Booster Charging Cable and a standard USB-Charger.

The ANTELOPE.2C-BOOSTER is intended only to power and regulate the electrical stimulation for the ANTELOPE.TANK-TOP and ANTELOPE.CALF-GUARDS.



7.7 ANTELOPE.APP

The ANTELOPE.APP acts as an alternative external control system to regulate the stimulation of ANTELOPE.TECHWEAR.

Without connecting the ANTELOPE.APP with the ANTELOPE.BOOSTER it is not possible to begin electrical stimulation.

The following stimulation programs are available via the ANTELOPE.APP:

	Endurance	Strength	Massage
Frequency	40 Hz	60-100 Hz	60 Hz
Impulse Wide	400 μ s	350 μ s	200 μ s
Impulse Typ	Contrast	4-second interval	2,5 seconds stimulation 1 second ramp

7.8 ANTELOPE.SPRAY

The electrode contact spray is a conductive liquid which, when used, can improve the conductivity between the electrodes and the skin.

Application: Spray the electrodes with the spray. 1-2 sprayers are sufficient. Hold the bottle vertically and spray the electrodes with a distance of approx. 15 cm between the spray head and the electrode.

Ingredients: (CTFA): NA, K, Mg, NH, CL, So Ca, NCR

7.9 BOOSTER Charging Cable

The BOOSTER Charging Cable is a micro USB cable which connects to the ANTELOPE.8C-and ANTELOPE.2C-BOOSTER for the purpose of charging.



8. INSTRUCTIONS FOR USE

NOTE

We recommend using ANTELOPE.Techwear at least once to max. twice a week for 20 minutes. Between training sessions, sufficient time for regeneration should be allowed. Before, during and after your training you should drink enough water.

8.1 Putting on the ANTELOPE.SUIT

1. Open the three zippers of the ANTELOPE.SHIRT - one on each side and one in the middle.
2. Put on the shirt and make sure that the electrodes lie flat on your skin without folds or wrinkles.
3. Close the zippers.
4. Put on the ANTELOPE.SHORTS

NOTE

The electrodes must be placed directly onto the skin. Excessive hair growth or extremely dry skin can affect the stimulation. Ensure that the electrodes are placed directly on the targeted muscle.

8.1.1 CONNECTING THE ANTELOPE.SUIT AND THE ANTELOPE.8C-BOOSTER

DANGER

DO NOT CONNECT THE ANTELOPE.SUIT WITH ANTELOPE.8C-BOOSTER IF THE BOOSTER IS TURNED ON.

1. On the back of the BOOSTER there is a grid of buttons. Hanging from your ANTELOPE.SHORTS there is a connector with buttons. To connect the two, place the shorts connector on the lower-most buttons of the BOOSTER.
2. On the side of your ANTELOPE.SHIRT there is another grid of buttons – this is the baseplate. To connect your shirt to the BOOSTER, place the BOOSTER on the baseplate.

8.2 Putting on the ANTELOPE.TANK-TOP

1. Open the zippers on front and on each side of the TANK-TOP
2. Put on the TANK-TOP and make sure that the electrodes lie flat on your skin without folds or wrinkles.
3. Close the zippers.

8.2.1 Connecting the ANTELOPE.TANK-TOP and the ANTELOPE.2C-BOOSTER

DANGER

DO NOT CONNECT THE ANTELOPE.TANK-TOP WITH ANTELOPE.2C-BOOSTER IF THE BOOSTER IS TURNED ON.

1. Connect the magnetic button ending of the external cables to the magnetic buttons on the textile. One cable pair should connect to the front buttons of the textile and the other pair to the back.
2. Connect the jack plugs of the external cables to the jack plug input at the bottom of the 2C-BOOSTER.



NOTE

Be sure to observe which channel (I or II) the external cables are connected to.

8.3 Putting on the ANTELOPE.CALF-GUARDS

1. Open the zipper on each CALF-GUARD.
2. Put on the CALF-GUARDS and make sure that the electrodes lie flat on your skin without folds or wrinkles.
3. Close the zippers.

8.3.1 Connecting the ANTELOPE.CALF-GUARDS and the ANTELOPE.2C-BOOSTER

DANGER

DO NOT CONNECT THE ANTELOPE.CALF-GUARDS WITH ANTELOPE.2C-BOOSTER IF THE BOOSTER IS TURNED ON.

1. Connect the magnetic button ending of the external cable to the magnetic buttons on the textile. Only one cable pair should be used to connect both CALF-GUARDS.
2. Connect the jack plugs of the external cables to the jack plug input at the bottom of the 2C-BOOSTER.

NOTE

Be sure to observe which channel (I or II) the external cables are connected to.

8.4 Switching the ANTELOPE.2C-BOOSTER and ANTELOPE.8C-BOOSTER ON/OFF

- On: Press and hold the [+]-button for three seconds.
- Off: Press and hold the [-]-button for three seconds.



8.5 Connecting the ANTELOPE.2C-BOOSTER and ANTELOPE.8C-BOOSTER to the ANTELOPE.APP via Bluetooth

NOTE

The ANTELOPE.APP must first be downloaded via the App Store or Google Play Store before connecting.

1. Hold the [+] button on the BOOSTER until the blue shining LED begins to flash. This indicates the BOOSTER is searching for a compatible device via Bluetooth.
2. Switch the Bluetooth ON from your compatible device
3. Open the ANTELOPE.APP on your device and select the “connect” tab. Your Booster appears on this page. Tap on the Booster to connect and select the options in the fields to continue.

NOTE

- After switching on the BOOSTER and before connecting to a Bluetooth device, the BOOSTER will display a constant green LED.
- After connecting to the APP via Bluetooth, the LED will change to a constant blue light.
-

DANGER

If the connection to a Bluetooth device is interrupted for several minutes, the BOOSTER DOES NOT switch off automatically. If a connection between a Bluetooth device and the BOOSTER is interrupted, immediately disconnect the connection between BOOSTER and Baseplate. (see 8.7.1)

8.6 Starting the Stimulation

NOTE

Stimulation can only be started from the ANTELOPE.APP. App and BOOSTER must be connected before.

1. Tap the EMS tab of the ANTELOPE.APP and select a program.

NOTE

The duration of each program can be adjusted.

2. Tap the “start” button at the bottom of the screen to begin stimulation.

8.7 Regulating Stimulation

- Once the stimulation has been started it can be regulated using the ANTELOPE.APP and/or directly from the ANTELOPE. BOOSTER.
- Pressing the [+] on the EMS tab of the ANTELOPE.APP OR on the BOOSTER, will increase the intensity by one unit on all channels.
- Pressing the [-] on the EMS tab of the ANTELOPE.APP OR on the BOOSTER, will reduce the intensity by one unit on all channels.

DANGER

If stimulation cannot be felt at an intensity of 25%, SWITCH OFF the BOOSTER and APPLY ANTELOPE. SPRAY directly to the electrodes in the textile. Then restart the ANTELOPE.APP and make



sure that all intensity levels are set to 0. Once this process is completed, restart using your ANTELOPE.TECHWEAR according to the instructions in this manual. (see 8.1).

NOTE

Tapping the muscle groups on the EMS tab of ANTELOPE.APP will enable individual regulation of specific muscle groups.

8.7.1 Ending the Stimulation

Stimulation can be ended by:

- Pressing the [-] button on the BOOSTER for 3 Seconds.
- Pressing “pause” on the ANTELOPE.APP.

OR

DANGER

- Directly detaching the BOOSTER from the Baseplate or External Cables by pulling with force.

8.8 Using the ANTELOPE.2C-BOOSTER and ANTELOPE.8C-BOOSTER

NOTE

Please fully charge the ANTELOPE.8C-BOOSTER before initial use.

8.8.1 Battery status

- Whilst charging the BOOSTER will display a flashing green LED.
- Once you disconnect the BOOSTER from the charger, the LED will switch off.
- Once the remaining charge drops under 20%, the BOOSTER will display a red LED.

8.8.2 Charging the BOOSTER

The BOOSTER takes approximately one hour to fully charge and it provides approximately 6 sessions.

To avoid damage to your equipment please check the following requirements before charging the BOOSTER:

- Your charging plug is compatible with your country's power socket.
- The nominal voltage in your electrical network fits the requirements of the charging device you are using.



9. TROUBLE SHOOTING

Problem	POSSIBLE CAUSE	SOLUTION
Unpleasant feeling from Stimulation	Skin condition is dry	<ul style="list-style-type: none"> Spray the ANTELOPE.SPRAY directly on the electrodes. Drink enough water before, during and after training. If necessary, start your training with a light warm-up without stimulation. <p>DANGER If stimulation cannot be felt at an intensity of 25%, SWITCH OFF the BOOSTER and APPLY ANTELOPE. SPRAY directly to the electrodes in the textile. Then restart the ANTELOPE.APP and make sure that all intensity levels are set to 0. Once this process is completed, restart using your ANTELOPE.TECHWEAR according to the instructions in this manual. (see 8.1).</p>
	Stimulation intensity is too high	<ul style="list-style-type: none"> Reduce stimulation intensity Stop stimulation
	Defect electrode	Please contact our Customer Care-Team.
Stimulation is weak / Cannot feel Stimulation	Skin Condition is dry	<p>Apply ANTELOPE.SPRAY directly onto the electrodes in the textile.</p> <p>DANGER If stimulation cannot be felt at an intensity of 25%, SWITCH OFF the BOOSTER and APPLY ANTELOPE. SPRAY directly to the electrodes in the textile. Then restart the ANTELOPE.APP and make sure that all intensity levels are set to 0. Once this process is completed, restart using your ANTELOPE.TECHWEAR according to the instructions in this manual. (see 8.1).</p>
	Stimulation Intensity is too low	<p>Gradually increase stimulation intensity.</p> <p>DANGER If stimulation cannot be felt at an intensity of 25%, SWITCH OFF the BOOSTER and APPLY ANTELOPE. SPRAY directly to the electrodes in the textile. Then restart the ANTELOPE.APP and make sure that all intensity levels are set to 0. Once this process is completed, restart using your ANTELOPE.TECHWEAR according to the instructions in this manual. (see 8.1).</p>
	Defect electrode	Please contact our Customer Care-Team.



Problem	POSSIBLE CAUSE	SOLUTION
BOOSTER will not connect to ANTELOPE.APP	GPS is not activated on your Android device	Activate GPS on your Android device.
	Bluetooth connection was not established via ANTELOPE.APP	Always establish Bluetooth connection within the ANTELOPE.APP, not via the Bluetooth search on your device.
	Bluetooth compatibility issues	<ul style="list-style-type: none"> • Close or reinstall the app in task manager. • Log in. • Start the search for your BOOSTER. • Turn on the BOOSTER. • Tap once on the displayed BOOSTER. • If a connection is still not possible, clear the Bluetooth cache and restart the search.
The stimulation is too strong in some areas and too weak in others	Stimulation of all muscle groups has been increased at once	Deselect the muscle groups from the ANTELOPE.APP and adjust accordingly.
	Skin Condition varies	DANGER SWITCH OFF the BOOSTER and APPLY ANTELOPE. SPRAY directly to the electrodes in the textile. Then restart the ANTELOPE.APP and make sure that all intensity levels are set to 0. Once this process is completed, restart using your ANTELOPE.TECHWEAR according to the instructions in this manual. (see 8.1).
	Defect electrode	Please contact our Customer Care-Team.



10. SAFETY INSTRUCTIONS

Please follow the safety instructions. Doing otherwise may cause damage to the device and injury.

- Store the ANTELOPE.TECHWEAR out of the reach of children in order to prevent them from swallowing parts of the product.
- You must not try to replace the battery pack yourself. Opening the BOOSTER yourself may cause damage.
- Do not touch the electrodes with your fingers while operating your device.
- Do not use the ANTELOPE.TECHWEAR while driving, operating machines or manual labour.
- Do not use the ANTELOPE.TECHWEAR in wet conditions such as heavy rain or snow, while bathing, showering or swimming.
- Never put the BOOSTER or the cables into the washing machine. The textile including the electrodes is washable by hand.
- Start at low intensities and slowly increase the power. Do not deviate from the instructions given in this manual.
- While working out actively with the ANTELOPE.TECHWEAR always keep your muscles tense or keep moving.



11. CARE AND MAINTENANCE

11.1 BOOSTER CARE

- Store your BOOSTER in a cool, dry place.
- Charge your BOOSTER at least every six months.

11.2 Washing instructions

The textile consists of 54% polyamide, 36% polypropylene and 10% elastane. It is hand-washable WITHOUT the BOOSTER. To ensure maximum durability of the ANTELOPE.TECHWEAR please follow the instructions:

- The textile is washable per hand (max. 30°C).
- Do not tumble-dry. Hang damp garment from line or bar, in or out doors.

NOTE

Textile colour may bleed during washing.

12. DISPOSAL

Products with an ANTELOPE logo must not be disposed of with your household waste. Please dispose it in compliance with statutory regulations. The equipment cannot be discarded with household refuse. The equipment must be delivered to a suitable collection point for disposal. By doing so, you will be contributing to the safeguarding of natural resources and health.



13. CLAIMS FOR DEFECTS / WARRANTY

For all ANTELOPE.PRODUCTS we have a warranty period of 24 months according to the legal regulations, towards entrepreneurs the period is 12 months.

The electrodes are consumable materials which are subject to natural wear and tear. In addition to the general life span of approx. one year, the durability depends strongly from the handling and the right care. For these reasons, no guarantee of durability can be given.

If your electrodes have exceeded their service life of approx. one year, we will gladly exchange them for a corresponding material and processing fee. In addition, there is a service charge of 19.90 € and shipping costs for the outward and return delivery of 19.00 €.* These are valid from the 6th month after purchase. These will be invoiced to you after completion of the return.

Within the first 6 months the service flat rate and the shipping costs will be paid by us.

You will not receive guarantees in the legal sense from us, unless these are expressly stated in the order confirmation for the respective article. Damage that is not covered by the warranty can be repaired at a charge. The respective costs will be determined and communicated.

If you have any further questions regarding claims for defects and warranty please contact our Customer Care Team.

* all prices listed are gross prices and valid from June 2020



14. LABELS

The following labels are printed on the package or the user manual (colour and size may vary):



By displaying the CE mark the manufacturer confirms that the product complies with all necessary requirements of the EU regulations. Conformity assessment procedures have been completed.



Manufacturer Details



Serial Number



Critical information (as per the user manual)



Do not use if the package is damaged



Important instruction inside



This device must be separated from household waste and recycled as electronic waste



Wash by hand



Do not iron



Do not tumble dry



Do not dry clean



Do not bleach



Handle with care



Do not wring



Temperature limits to which the medical device can be safely exposed



Class II device with internal power supply



15. TECHNICAL SPECIFICATIONS

15.1 ANTELOPE.8C-BOOSTER

Parameter	Description
Model	ANTELOPE.8C-BOOSTER
Storage Conditions	Temperature (0-35°C), Humidity (20 – 85%)
Operating Conditions	Temperature (0-40°C), Humidity (20 – 65%)
Measurements	14,2cm x 8,5cm x 2,6cm
Weight	220g
Current	max. 80mA
Frequency	1-2000 HZ (depending on the program)
Impulse Width	50 µs - 500µs
Max. Transmission power	< 10 dBm
Frequency band	2402 MHz – 2480 MHz

The serial number of the BOOSTER can be found on the device.

15.2 ANTELOPE.2C-BOOSTER

Parameter	Beschreibung
Model	ANTELOPE.2C-BOOSTER
Storage Conditions	Temperature (0-35°C), Humidity (20 – 85%)
Operating Conditions	Temperature (0-40°C), Humidity (20 – 65%)
Measurements	10,3cm x 4,9cm x 1,9cm
Weight	80g
Current	max. 100mA
Frequency	1-5000 HZ (depending on the program)
Impulse Width	50 µs - 400µs
Max. Transmission power	< 10 dBm
Frequency band	2402 MHz – 2480 MHz

The serial number of the BOOSTER can be found on the device.



16. COMPANY INFORMATION

ANTELOPE - part of the Beurer group - BEURER GmbH
Niddastrasse 64, 60329 Frankfurt Main – Germany
Company headquarters:
Ulm – Soeflinger Strasse 218, 89077 Ulm – Germany

Chairman: Dietrich Leisner
Managing Directors:
Marco Buehler, Georg Walkenbach, Oliver Neuschl
Commercial Register: Local court Ulm, HRB 722213
VAT-ID: DE 147040787

Contact:

Phone.: +49 69 25786744
E-Mail: info@antelope.de
Website: www.antelope.de



